



## INSTRUCTION FOR PROPER USE

### CROWN POSITIONS:

pos. 1: Completely screwed tight: no correction possible

pos. 2: Crown unscrewed and slightly pulled to reach intermediate "correction" position (click):  
a) by turning left (counter-clock-wise), you select calendar day of month;  
b) by turning right (clock-wise), you move red 24-hour-hand to the desired 24-hour mark on the dial.

pos. 3: Crown unscrewed and pulled out completely: normal time setting of hour and minute hand.

## AIRMAN 7 ETA 2893-2 & 2671-2

dial 10 hours / 2 hours  
pull crown to set time of 1st destination

dial 8 hours / 4 hours  
pull crown to set time of 2nd destination

In order to secure waterproof quality, it is essential that you push, or push and screw, the crowns tight after every correction.



REF. 3829 / 3881 / 3882 / 3841

AIRMAN 7

ETA 2893-2 & 2671-2