



## INSTRUCTION FOR PROPER USE



ETA 7750

ETA 7750

### CROWN POSITIONS:

**Pos. 1** completely screwed tight: no correction possible

**Pos. 2** pull crown to position 2 to reach intermediate «correction» position (click). by turning right (clock-wise), you select calendar day of the month  
**Date correction is impossible between 8h PM and 2h AM, it will damage the movement**

**Pos. 3** crown pulled out completely: normal time setting of hour and minute hand.

In order to secure waterproof quality, it is essential that you push, or push and screw, the crowns tight after every correction.