



## INSTRUCTION FOR PROPER USE



### CROWN POSITIONS:

Pos. 1 completely screwed tight: no correction possible

Pos. 2 crown unscrewed and slightly pulled to reach intermediate «correction» position (click)

by turning right (clock-wise), you select calendar day of the month  
Date correction is impossible between 8h PM and 2h AM, it will damage the movement.

Pos. 3 crown unscrewed and pulled out completely: normal time setting of hour and minute hand.

In order to secure waterproof quality, it is essential that you push, or push and screw, the crowns tight after every correction.

## ETA 7750 RUNNING SECOND

ETA 7750 RUNNING SECOND